

SUPER BINDER-P

Leather Auxiliary

Technical Information

Nature :

Medium Soft fixable protein binder

Analytical Data :

Appearance	:	Light Yellowish
Solid matter	:	20% ± 1%
pH	:	7.0 – 8.0
Charge	:	Anionic

Behaviour :

SUPER BINDER-P is a solution of medium viscosity & gives a clear high gloss elastic film with silky feel. It is mainly used for glazed & polish finishes but also be used in resin finishes to remove tackiness for excellent plate release properties. SUPER BINDER-P may be used in base coats and top coats.

Application :

Glaze upper (Base Coat) :

Super an Pigment	50 Parts
SuperAlene	50 Parts
Super Binder-P	200 Parts
Super Wax-W	40 Parts
Super Peneto I	20 Parts
Water	640 Parts

3-4 Cross Coat, Dried well.

Top Coat :

Super Binder-P	150 Parts
Super Binder-H	50 Parts

Water 800 Parts

1 cross coat spray, dried well.

Fixing Coat :

Formalin 300 parts

Acetic Acid 15 Parts

Water 900 Parts

1 cross coat spray dry, glazed or plate

Storage :

Non dangerous product, store between 5⁰C to 40⁰C

Recommendations are based on current knowledge and experience but without engagement and warranty.